















ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE
 ITEM NO / NO ARTICLE: SICI3SET(530012)




HARDWARE LIST / LISTE DES PIECES


A		2
B		2
C		2
D		2
E		2

F		1
G		1
H		1
W		16
X		8
Y		24
Z		1


STEP 1(ETAPE 1)




STEP 2(ETAPE 2)



STEP 3(ETAPE 3)




STEP 4(ETAPE 4)



STEP 5(ETAPE 5)

FRONT

C



STEP 6(ETAPE 6)

E

D

